

Agricultural Pesticides

Less and Smarter



Taking action

**Calibrate
your boom sprayer**

- Editor : **Roch Lavoie**, instructor
Institut de technologie agroalimentaire
de La Pocatière
(La Pocatière Institute of Agri-food Technology)
- Production : **“Stratégie phytosanitaire”**
for the Department of the Environment
and Sustainable Development
- Coordination : For “Stratégie phytosanitaire”:
Raymond-Marie Duchesne, biologist- entomologist
Yvon Brochu, engineer
Luc Vallières, information agent
- For the Institut de technologie agroalimentaire
de La Pocatière (La Pocatière Institute of
Agri-Food Technology) :
Josée Lauzier, agronomist
- Design and
Layout : **Katapulte** Communication-Marketing
- Linguistic
revision : **Suzanne Lemieux**,
Institut de technologie agroalimentaire de
La Pocatière (The La Pocatière Institute of
Agri-Food Technology)
- Translation : The Quebec Farmers’ Association

ISBN 2-550-40742-3

Dépôt légal - Bibliothèque nationale du Québec, 2003
Dépôt légal - Bibliothèque nationale du Canada, 2003

Agricultural Pesticides

Less and Smarter

Table of Contents

Introduction	2
What you need to calibrate your boom sprayer	3
Components to check and clean	4
Determining the spray width of the nozzles	5
Determining ground speed	6
Determining the average output of the spray nozzles	7
Nozzle flow rate	9
Test Results Table – examples	10
Test Results Tables – Charts A, B and C	12



Calibrating your boom sprayer

The sprayer is a precision instrument which allows the application of products that control crop pests.

Despite its ease of use, regular checking and adjustments are necessary to ensure the quality of applications as well as the quantity applied, so that the environment is protected.

This document will provide you with procedures and tips to improve the calibration of your equipment. It will help you save time and money, while minimizing the environmental impact of applying pesticides.

Within the framework of la Stratégie phytosanitaire, the Ministère de l'Agriculture, des Pêcheries et de l'Alimentation du Québec, in partnership with the agriculture industry, launched the ACTION-RÉGLAGE project for boom sprayers in 1998.

In every region of Québec, there are accredited people with the knowledge to help you calibrate your sprayer properly. Don't hesitate to contact them.

List of accredited people

[http:// www.agr.gouv.qc.ca/dgpar/agroenv/Strategie/personnes/sp05-201.html](http://www.agr.gouv.qc.ca/dgpar/agroenv/Strategie/personnes/sp05-201.html)



WHAT YOU NEED IN ORDER TO CALIBRATE YOUR BOOM SPRAYER:

- **Check and clean the sprayer components.**

- **Determine :**
 - Nozzle output;
 - Ground speed of tractor with the boom;
 - The spray width of the nozzles.

- **The following material :**
 - Paper and pencil;
 - Watch or stopwatch;
 - Calculator;
 - Two pickets or ground markers;
 - 50 metre measuring tape;
 - Tape to measure the distance between nozzles;
 - Graduated containers marked off in millilitres;
 - Soft brush for cleaning the nozzles.

Before beginning any work on your equipment or while handling or applying pesticides, make sure you are wearing proper protective garments.





COMPONENTS TO CHECK AND CLEAN

Tank

- interior and exterior cleanliness (residue)
- leaks
- drainage valve
- intake filter
- hydraulic agitation nozzle(s)
- mechanical agitation system

Pump

- lubrication
- pneumatic pressure pulsation damper (air chamber)
- Power take off (PTO) shaft


Circulation system

- main filter
- line or nozzle filters
- suction and transfer hoses
- hose connectors (leaks)
- controls, cocks and valves
- pressure regulator
- bypass line (return of regulator)
- agitation line
- pressure gauge stability and accuracy

Sprayer components

- nozzles (number, alignment, cleanliness)
- visual inspection of spray pattern
- boom (height, level, stability)

SUPPLYING THE BOOMS



DETERMINING THE NOZZLE SPRAY WIDTH

Measure the spacing of the nozzles (center to center) in several places, in order to calculate an average in **centimetres**. In order to obtain a **proper spray pattern**, the spacing between nozzles must be even. Spacing variations of even 5% from the average (ex: 2.5 cm for 50 cm) should be corrected on the equipment.

Average space between nozzles: $L = \underline{\hspace{2cm}}$ **centimetres**

DETERMINING GROUND SPEED

☑ Preparations:

1. Measure and mark off a distance of 50 metres (164 feet) on ground which is similar to the surface and soil conditions of the area to be treated;
2. Fill half the spray tank with water;
3. Check the tire pressure on the tractor and the sprayer;
4. Adjust motor speed so that the PTO revs at 540 r.p.m.;
5. Select a forward gear;
6. If possible, lower the boom to check the sprayer's stability;
7. Start several metres before the first marker to stabilize motor speed before beginning the test.

☑ Calculations:

8. Get the average time, **in seconds**, it takes to travel 50 meters (**minimum of 2 tries**).
9. Calculate the speed (**S**) using the following table or the table of results. (See annex.)

Speed based on time necessary to travel 50 meters

Sec/50 m	16	17	18	19	20	21	22	23	24	25	26	27	28
Speed in km/h	11.3	10.6	10.0	9.5	9.0	8.6	8.2	7.8	7.5	7.2	6.9	6.7	6.4
Sec/50 m	29	30	31	32	33	34	35	36	37	38	39	40	41
speed in km/h	6.2	6.0	5.8	5.6	5.5	5.3	5.1	5.0	4.9	4.7	4.6	4.5	4.4

DETERMINING AVERAGE NOZZLE OUTPUT

☑ Preparations:

1. Immobilize the equipment and adjust the motor speed to be identical to that used to determine your ground speed;
2. Open up the controls, the cocks and valves appropriate for the job to be done;
3. Adjust required pressure according to the nozzles and the type of application. Note the pressure.
Keep in mind that:
 - Higher pressure means finer droplets and an increase in the risk of drift;
 - That pressure must be quadrupled (4X) in order to double (2X) the output of a nozzle.

☑ Measurements and calculations:

4. Using a container graduated in millilitres, collect the output of each nozzle over a 30 or 60 second period;
5. Write the results (in millilitres) for each nozzle in the test tables (see annex).
6. Calculate the initial average of the output gathered from all the nozzles.

☑ Interpretation of the results:

7. Discard result from any nozzle whose output differs by more than 10% from the average;
 - If less than 20% (ex: 6 nozzles out of 30) of the nozzles are discarded, a second average must be recalculated with the remaining nozzles;
 - If more than 20% of the nozzle outputs are discarded, the output of the boom will not be uniform. It would be best to change all the nozzles and start your volume tests again.



DETERMINING AVERAGE OUTPUT OF THE NOZZLES (continued)

8. This average will allow you to obtain the output:
- If your tests were based on 30 second periods, multiply the average obtained by 2 and divide by 1000,
(O) in _____ liters/minute;
 - If your tests were based on 60 second periods, divide the average obtained by 1000,
(O) in _____ liters/minute.

PLEASE NOTE:

Before applying any pesticides, don't forget to make the corrections to the nozzles whose output was discarded in your tests (i.e.: cleaning or replacement).

9. Checking against the manufacturer's specifications

If you have access to the manufacturer's charts for your type of nozzles, compare your results to the manufacturer's specifications. **This can help you discover if your nozzle tips are worn, whether the nozzles are properly angled, whether their spray pattern is standard and if the droplet size is consistent with the pressure used.**

- If the difference between your average output and the manufacturer's output is over 10%, your nozzles may be worn. If they are new, then your pressure gauge may be indicating a pressure that is lower than the real pressure.
- If the difference between your average output and the manufacturer's output is less than 10%, your pressure gauge may be indicating a pressure that is higher than the real pressure.

NOZZLE FLOW RATE

You can find the flow rate of your sprayer, that is the quantity of liquid applied per surface unit, by measuring the volume of liquid from one nozzle, under certain conditions.

METHOD:

1. Identify a nozzle whose output is the closest to the average output calculated for the whole group (see example on page 10);
2. Adjust the device to the same pressure as used in the tests to determine the average output;
3. Choose, from the speed test results, the speed appropriate to the type of application (taking the stability of the boom, the driving precision, etc., into account);
4. Collect the spray from the nozzle tip for the same period of time as used in the speed test;
5. Multiply the volume collected (in millilitres) by one of the following factors:

Multiplication factors to determine the rate of application (1/ha) using the volume of liquid from one nozzle (ml) gathered for a distance of 50 metres.	
Space between nozzles	Multiplication factor
30 cm	0.667
50 cm	0.4
20 inches (50.8 cm)	0.394
30 inches (76.2 cm)	0.262

Table of results (with the example on page 10)

Nozzle #	Gear selection	Time (s)	Volume of liquid (ml)	Multiplication factor	Rate of application (l /ha)
5	M-2	33.5	560	0.394	220 l / ha

MY TEST RESULTS TABLE – EXAMPLE

Nozzle test tables

Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)	Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)
1	500	500	16	510	510
2	525	525	17	525	525
3	525	525	18	510	510
4	500	500	19	500	500
5	510	510	20	500	500
6	500	500	21		
7	450	<i>discarded</i>	22		
8	525	525	23		
9	525	525	24		
10	500	500	25		
11	525	525	26		
12	525	525	27		
13	500	500	28		
14	510	510	29		
15	525	525	30		

**SEE PROCEDURE
ON PAGE 7**

1st Total	10190 ml
1st average	510 ml
-10% average	460 ml
+10% average	560 ml

2nd Total	9740 ml
2nd average	513 ml

Average output table (O in liters/minute)



Type of nozzle	XR 8003	
Pressure used	35 psi	
Manufacturer's output specs (<i>liters/min</i>)	1.08	
Test time (<i>seconds</i>)	30	
Average volume (<i>milliliters</i>)	513	
Average output (O – liters/min)	1.03	
% variation = $\frac{(O - \text{manufacturer's output})}{\text{manufacturer's output}} \times 100$	-4.6 %	

MY TEST RESULTS TABLE - EXAMPLE

Speed of advance (S in kilometers / hour)			
Tractor		M-H	
Motor speed		1950 R.P.M.	
Gear		M-2	M-3
Average time (<i>seconds</i>)		33.5	28
Distance (<i>metres</i>)		50	50
Speed (S - km/h)		5.4	6.4
$S = \frac{50 \text{ metres} \times 3.6}{\text{time}} \quad \text{ou} \quad \frac{180}{\text{time}}$			

Calculation of application rate (Q in liters/ hectare)		
Average output calculated (O- liters/min)	1.03	1.03
Width between nozzles (W – centimeters)	50.8	50.8
Speed (S – km/hour)	5.4	6.4
Application rate (Q) = $\frac{O \times 60000}{W \times S}$	225	190

Calculation of the quantity of product per tank		
Dose (quantity of product recommended/hectare)	3.0 liters	3.0 liters
Tank capacity in liters (C – liters)	800	800
Calculated rate of application (Q - liters/ha)	225	190
Quantity/tank = Dose x tank capacity (C)	10.6	12.6
Calculated rate of application (Q)	liters	liters
Area covered with one tank Area (A) = $\frac{\text{Tank capacity (C)}}{\text{Calculated rate of application (Q)}}$	3.5 ha	4.2 ha

Boom height relative to target spray area			
			
Spacing	Height	Spacing	Height
50 cm	50 à 70 cm	50 cm	30 à 50 cm
75 cm	90 à 110 cm	75 cm	50 à 75 cm

MY TEST RESULTS TABLE – Chart A

ADJUSTMENT DATE:

Nozzle test tables

Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)	Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)
1			16		
2			17		
3			18		
4			19		
5			20		
6			21		
7			22		
8			23		
9			24		
10			25		
11			26		
12			27		
13			28		
14			29		
15			30		

1st Total	
1st average	
-10% average	
+10% average	

2nd Total	
2^c average	

Average output table (O in liters/minute)



Type of nozzle		
Pressure used		
Manufacturer's output specs (<i>liters/min</i>)		
Test time (<i>seconds</i>)		
Average volume (<i>milliliters</i>)		
Average output (O - <i>liters/min</i>)		
% variation = $\frac{(O - \text{manufacturer's output})}{\text{manufacturer's output}} \times 100$		

MY TEST RESULTS TABLE – Chart A

Speed of advance (S in kilometers / hour)			
Tractor			
Motor speed			
Gear			
Average time (<i>seconds</i>)			
Distance (<i>metres</i>)			
Speed (S - <i>km/h</i>)			
S = $\frac{50 \text{ meters} \times 3.6}{\text{time}}$		ou	$\frac{180}{\text{time}}$

Calculation of application rate (Q in liters/ hectare)		
Average output calculated (O- <i>liters/min</i>)		
Width between nozzles (W – <i>centimeters</i>)		
Speed (S – <i>km/hour</i>)		
Application rate (Q) = $\frac{O \times 60000}{W \times S}$		

Calculation of the quantity of product per tank		
Dose (<i>quantity of product recommended/hectare</i>)		
Tank capacity in liters (C – <i>liters</i>)		
Calculated rate of application (Q - <i>liters/ha</i>)		
Quantity/tank = Dose x tank capacity (C)		
Calculated rate of application (Q)		
Area covered with one tank Area (A) = Tank capacity (C) Calculated rate of application (Q)		

Boom height relative to target spray area			
			
Spacing	Height	Spacing	Height
50 cm	50 à 70 cm	50 cm	30 à 50 cm
75 cm	90 à 110 cm	75 cm	50 à 75 cm

MY TEST RESULTS TABLE – Chart B

ADJUSTMENT DATE:

Nozzle test tables

Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)	Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)
1			16		
2			17		
3			18		
4			19		
5			20		
6			21		
7			22		
8			23		
9			24		
10			25		
11			26		
12			27		
13			28		
14			29		
15			30		

1st Total	
1st average	
-10% average	
+10% average	

2nd Total	
2^e average	

Average output table (O in liters/minute)



Type of nozzle		
Pressure used		
Manufacturer's output specs (<i>liters/min</i>)		
Test time (<i>seconds</i>)		
Average volume (<i>milliliters</i>)		
Average output (O - <i>liters/min</i>)		
% variation = $\frac{(O - \text{manufacturer's output})}{\text{manufacturer's output}} \times 100$		

MY TEST RESULTS TABLE – Chart B

Speed of advance (S in kilometers / hour)			
Tractor			
Motor speed			
Gear			
Average time (<i>seconds</i>)			
Distance (<i>metres</i>)			
Speed (S - <i>km/h</i>)			
$S = \frac{50 \text{ meters} \times 3.6}{\text{time}} \quad \text{ou} \quad \frac{180}{\text{time}}$			

Calculation of application rate (Q in liters/ hectare)		
Average output calculated (O- <i>liters/min</i>)		
Width between nozzles (W – <i>centimeters</i>)		
Speed (S – <i>km/hour</i>)		
Application rate (Q) = $\frac{O \times 60000}{W \times S}$		

Calculation of the quantity of product per tank		
Dose (<i>quantity of product recommended/hectare</i>)		
Tank capacity in liters (C – <i>liters</i>)		
Calculated rate of application (Q - <i>liters/ha</i>)		
Quantity/tank = Dose x tank capacity (C)		
Calculated rate of application (Q)		
Area covered with one tank Area (A) = $\frac{\text{Tank capacity (C)}}{\text{Calculated rate of application (Q)}}$		

Boom height relative to target spray area			
			
Spacing	Height	Spacing	Height
50 cm	50 à 70 cm	50 cm	30 à 50 cm
75 cm	90 à 110 cm	75 cm	50 à 75 cm

MY TEST RESULTS TABLE – Chart C

ADJUSTMENT DATE:

Nozzle test tables

Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)	Nozzle #	Volume (1 st avg) (ml)	Volume (2 nd avg) (ml)
1			16		
2			17		
3			18		
4			19		
5			20		
6			21		
7			22		
8			23		
9			24		
10			25		
11			26		
12			27		
13			28		
14			29		
15			30		

1st Total	
1st average	
-10% average	
+10% average	

2nd Total	
2^e average	

Average output table (O in liters/minute)

Type of nozzle		
Pressure used		
Manufacturer's output specs (<i>liters/min</i>)		
Test time (<i>seconds</i>)		
Average volume (<i>milliliters</i>)		
Average output (O - <i>liters/min</i>)		
% variation = $(O - \text{manufacturer's output}) \times 100$ manufacturer's output		

MY TEST RESULTS TABLE – Chart C

Speed of advance (S in kilometers / hour)

Tractor			
Motor speed			
Gear			
Average time (<i>seconds</i>)			
Distance (<i>metres</i>)			
Speed (S - km/h)			
$S = \frac{50 \text{ meters} \times 3.6}{\text{time}} \quad \text{ou} \quad \frac{180}{\text{time}}$			



Calculation of application rate (Q in liters/ hectare)

Average output calculated (O- <i>liters/min</i>)		
Width between nozzles (W – <i>centimeters</i>)		
Speed (S – <i>km/hour</i>)		
Application rate (Q) = $\frac{O \times 60000}{W \times S}$		

Calculation of the quantity of product per tank

Dose (<i>quantity of product recommended/hectare</i>)		
Tank capacity in liters (C – <i>liters</i>)		
Calculated rate of application (Q - <i>liters/ha</i>)		
Quantity/tank = Dose x tank capacity (C)		
Calculated rate of application (Q)		
Area covered with one tank		
Area (A) = $\frac{\text{Tank capacity (C)}}{\text{Calculated rate of application (Q)}}$		

Boom height relative to target spray area

			
Spacing	Height	Spacing	Height
50 cm	50 à 70 cm	50 cm	30 à 50 cm
75 cm	90 à 110 cm	75 cm	50 à 75 cm

Visit our web sites :



www.agr.gouv.qc.ca/dgpar/agroenv/strategie-slv.html




**Institut de technologie
agroalimentaire
de La Pocatière**

www.italp.qc.ca



www.slv2000.qc.ec.gc.ca

**Agriculture, Pêcheries
et Alimentation**

Québec 

Publication 2002-03 (n°03-0048)